

## Implementation checklist for Datatal Flexi and with Mitel MiVo400

M=Mandatory

O= Optional

Step	Description	OK
<b>M</b>	Server hardware: Up to 400 users 2 cores, 4gb internal memory. Larger installations with 400 users or more 4 cores and 6 gb internal memory. Free disk space minimum 20 GB.	
<b>M</b>	Operating system: Windows server version 2012 or newer	
<b>M</b>	Windows patched with latest updates.	
<b>O</b>	Set a DNS name for the Flexi ipaddress	
<b>O</b>	Open port in external firewall, standard ports for; Flexi Presentity is Http TCP 80 or HTTPS 443 Telephony manager TCP 9692 <i>More info on ports, read Flexi installation guide</i>	
<b>O</b>	Web-Certificate, Its recommended to get a valid certificate from a certificate provider	
<b>M</b>	Configure and update OIP server, see Flexi implementation guide for Flexi and MiVo400 more info <ul style="list-style-type: none"> <li>- Sip configuration in Mivo400</li> <li>- OIP server, login, password,</li> </ul>	
<b>M</b>	Internet access, strongly recommended for license and installation of windows features	
<b>M</b>	Install Flexi using FlexiInstaller and flexiserversetup, reboot can be performed after preinstaller and SQL-server installation. If Setup prompt for it, Then reboot system!	
<b>M</b>	Follow instructions in setup and setupguide afterwards	
<b>M</b>	Configure CTStack according to PBX manual. CTStack configuration is reached at <a href="http://localhost:1339">http://localhost:1339</a> (in web browser)	
<b>M</b>	Install Flexi Voice Library from FlexiInstaller	